

### Installation Guidelines

---

#### KB577 Transition Strip

Data Sheet: Page 1 of 1 15.05.18

1. It should be ensured that all surfaces to which the profile is to be fixed are dry, flat and free from any contaminants.
2. Cut the profile top and base to the size required.
3. Place the base into position and mark the substrate through the pre-drilled holes.
4. Drill the marked substrate using a 6mm drill bit and once drilled insert the appropriate sized plug. (6mm = red plug).
5. Apply a bead of proprietary cartridge adhesive to the underside of the base section, then, ensuring the substrate is free from dust, firmly place the base into position. \*On timber subfloors, apply adhesive and fix using No6 wood screws.
6. Secure in place using a No6 fixing screw.
7. Taking the pre-cut top section and holding at a slight angle, align the fixing lugs on the underside of the top section with the base selection. Using a rubber mallet firmly strike the top section so it secures into the base section. Continue this process along the profile length until the whole of the top section sits securely in the base.
8. If any further information is required, please contact Gradus Technical Support on (+44)1625 428922