

### Installation Instructions

---

#### UMFA Matwell Frames

Data Sheet: Page 1 of 1 AH/NF 26.05.22

**These installation instructions apply to the following Gradus profiles only:**

UMFA12, UMFA18, UMFA25

1. Ensure that the substrate is sound, dry and free from contaminants.
2. Place the profile into position and set the top of the frame so it finishes flush with the top of the opposing floorcovering. (\*See note below)
3. Mark the substrate through the predrilled holes. Drill the substrate using a 6mm drill bit. Insert plug to suit.
4. Apply a proprietary cartridge adhesive to the back of the profile and screw the profile to the floor.
5. All corners should be mitre cut.
6. Once installed apply smoothing compound to the required level.

\* In areas where opposing floorcoverings are not installed, skim the profile to the correct height and level using a spirit level.

If any further information is required, please do not hesitate to contact Gradus Technical Services on (+44)1625 428922.