

Fitting instructions for Continuity Lighting:

1. Measure the fitted stair edging between end caps.



2. Using a PVC Conduit Cutter (or similar), cut the **LR1238 TUBE** to the required length of the recess, minus the length of the **LEDCHAM + BLANK** (as illustrated below).




3. Feed the **CONTINUITY FIBRE OPTIC ROD** through the **LR1238 TUBE**, then cut the **CONTINUITY FIBRE OPTIC ROD** with PVC Conduit Cutters (or similar), making sure there is 12mm excess at each end of the **LR1238 TUBE**.



4. Insert the **CONTINUITY FIBRE OPTIC ROD** into the **LEDCHAM**, then slide the **LR1238 TUBE** in place.



5. Fit the **BLANK** into the open end of the **LR1238 TUBE**.



6. Install the fully assembled **LR1238 TUBE** into the recess. When using in conjunction with an aluminium stair edging profile, use a bead of silicone behind the lighting to adhere the **LR1238 TUBE** to the profile.



If any further information is required, please do not hesitate to contact Gradus Technical Services on (+44)1625 428922.