

Cleaning & Maintenance Guidelines

UMFA Matwell Frames

Data Sheet: Page 1 of 1 AH/NF 26.05.22

These guidelines apply to the following Gradus profiles only:

UMFA12, UMFA18, UMFA25

This document has been compiled to help the user obtain optimum performance and satisfaction from their selected product:

Preventative Maintenance Programme

A regular scheduled maintenance programme should be employed to prevent the build-up of dirt and grease, which will reduce the anti-slip properties of the profile and detract from the overall appearance of the product.

Daily Cleaning

Brush down the profile using a soft bristled brush and remove dust particles from the insert by wiping with a damp cloth.

Twice Weekly or as Required

Brush down the profile using a soft bristled brush. With clean, warm water, apply a small amount of a non-soapy detergent to a wet green scotch pad and gently clean the surface of the profile along it's width. During the clean, the water must be changed on a regular basis. Do not soak the profile. Once the profile has been cleaned thoroughly rinse with fresh, clean water and dry with a dry lint free cloth.

On completion the profile should not be used until completely dry.

Aluminium Profile

Stubborn marks such as boot blacking may be removed from the aluminium profile by means of a green scotch pad and neutral detergent. Light surface scratches can be removed with careful use of fine wire wool and buffed with a soft cloth.

If any further information is required, please do not hesitate to contact Gradus Technical Services on (+44)1625 428922.